

•For use with Colonial Engineering, Inc. mounting kits V07501A, V08501A, V10501A, V17501A, V20501A



1\_Close valve to remove handle, and then open the valve with wrench



2\_Put Nylock nuts in place in mounting plate and put tape over them



3\_Washers and button screws in mounting plate



4\_Mounting plate and stem coupling in place



5\_Put long bolt with washers in top bracket



6\_Attach top bracket to mounting plate using screws and washers



7\_Top section mounted to actuator. Nest the valve stem into stem coupling through the top bracket



8\_Attach bottom bracket. You may have to squeeze it to align with screws. Use washers and Nylock Nuts.



Finished assembly\_VB-015 on TUBV